



Repair Parts List Air/Hydraulic Truck Jack

ZATJ-22S-4



AIR PUMP



Repair Parts List Air/Hydraulic Truck Jack

ZATJ-22S-4

No.	Part No.	Description	No.	Part No.	Description	No.	Part No.	Description
1.	ZATJ224-1	FRAME ASSY	27.	ZATJ022-28	O-RING	53.	ZATJ022-62	SCREW
2.	ZATJ224-2	COVER	28.	ZATJ224-28	RELEASE STEM	54.	ZATJ022-63	SPRING WASHER
3.	ZATJ022-4	WASHER	29.	ZATJ022-30	OIL PLUG	55.	ZATJ022-64	LEVER
4.	ZATJ224-4	SPRING WASHER	30.	ZATJ224-30	SPRIG WASHER	56.	ZATJ022-65	TUBE
5.	ZATJ224-5	BOLT	31.	ZATJ224-31	BOLT	57.	ZATJ022-66	WASHER
6.	ZATJ224-6	SHAFT	32.	ZATJ022-34	O-RING	58.	ZATJ022-67	SPRING
7.	ZATJ224-7	WHEEL	33.	ZATJ022-42	RAM	59.	ZATJ022-68	COTTER PIN
8.	ZATJ022-9	WASHER	34.	ZATJ022-43	BACKUP RING	60.	ZATJ022-69	LOCK PIN
9.	ZATJ224-9	C-RING	35.	ZATJ022-44	PACKING	61.	ZATJ022-70	COTTER PIN
10.	ZATJ224-10	VALVE BLOCK	36.	ZATJ022-91	RAM GUIDE RING	62.	ZATJ022-57	SPRING PIN
11.	ZATJ022-13	O-RING	37.	ZATJ022-92	SNAP RING	63.	ZATJ022-96	RING
12.	ZATJ022-14	SPRING WASHER	38.	ZATJ022-45	STUFFING NUT	64.	ZATJ022-71	BALVE BODY
13.	ZATJ022-15	BOLT	39.	ZATJ022-46	O-RING	65.	ZATJ022-77	AIR VALVE
14.	ZATJ022-16	VALVE BALL	40.	ZATJ022-47	DUST SEAL	66.	ZATJ022-95	AIR HOSE
15.	ZATJ022-99	SCREW	41.	ZATJ022-48	SLEEVE	67.	ZATJ022-82	ELBOW
16.	ZATJ022-17	PIECE	42.	ZATJ022-49	ADJUSTING SCREW	68.	ZATJ022-85	TUBE
17.	ZATJ022-18	VALVE BALL	43.	ZATJ022-51	HANDLE SOCKET	69.	ZATJ022-94	SPRING HANGER
18.	ZATJ022-19	VALVE SPRING-A	44.	ZATJ224-44	UNIVERSAL JOINT	70.	ZATJ022-93	RETURN SPRING
19.	ZATJ022-20	CPPER PACKING	45.	ZATJ022-54	HI-TEN BOLT	71.	ZATJ022-97	ELBOW
20.	ZATJ224-20	BOLT	46.	ZATJ022-55	WASHER	101.	ZATJ224-101	JACK ASSY
21.	ZATJ022-22	VALVE BALL	47.	ZATJ022-56	NUT	102.	ZATJ022-102	HANDLE ASSY
22.	ZATJ022-23	S.V.BALL SEAT	48.	ZATJ224-48	SPRING WASHER	103.	ZATJ224-103	VALVE BLOCK ASSY
23.	ZATJ022-24	S.V.SPRING	49.	ZATJ022-58	BOLT	104.	ZATJ022-104	AIR PUMP ASSY
24.	ZATJ022-25	S.V.ADJUSTINGSCREW	50.	ZATJ022-59	HANDLE	105.	ZATJ022-105	AIR VALVE ASSY
25.	ZATJ224-25	S.V.PACKING	51.	ZATJ022-60	RELEASE ROD			
26.	ZATJ224-26	PUSH NUT	52.	ZATJ022-61	KNOB			

AIR PUMP

No.	Part No.	Description	No.	Part No.	Description	No.	Part No.	Description
107.	ZATJ022-107	Cylinder	117.	ZATJ022-117	Spring Washer	126.	ZATJ022-126	Soundproof(B)
108.	ZATJ022-108	Valve Bldy	118.	ZATJ022-118	O-Ring	127.	ZATJ022-127	Ball
109.	ZATJ022-109	Valve	119.	ZATJ022-119	O-Ring	128.	ZATJ022-128	Screw
110.	ZATJ022-110	Cylinder Bolt	120.	ZATJ022-120	Ball	129.	ZATJ022-129	Piston
111.	ZATJ022-111	Gasket A	121.	ZATJ022-121	Seal Ring	130.	ZATJ022-130	Head Cap
112.	ZATJ022-112	Gasket B	122.	ZATJ022-122	O-Ring	131.	ZATJ022-131	Piston Rod
113.	ZATJ022-113	Seal Nut	123.	ZATJ022-123	Back-up Ring	132.	ZATJ022-132	Piston Plug
114.	ZATJ022-114	Spring	124.	ZATJ022-124	Pilot Piston Cushion	133.	ZATJ022-133	Piston Plate
115.	ZATJ022-115	Nut	125.	ZATJ022-125	Silent Cap	134.	ZATJ022-134	O-Ring
16.	ZATJ022	Cap Screw						